

NO FOOD Alarm - If re-priming of the pump delivery set is required, it is advisable to disconnect the enteral adapter from the patient's feeding tube while re-priming.

Is bag of pump delivery set empty?	YES ▶	Refill bag, re-prime delivery set and resume feeding.
▼ NO ▼		
Is air present in the tubing?	YES ▶	Has air been removed from bag of pump delivery set?
	NO ▶	Manually prime tubing by turning bag upside down, gently squeezing lower half of bag while pinching the teal colored tubing just below the "O" drop symbol. Hold this position until all air is removed from bag and tubing.
	YES ▶	Press and hold the PRIME key to move the air in the tubing past pump delivery set cassette and resume feeding. NOTE: If your pump is equipped with an auto prime option, refer to the Operator's Manual for details.
▼ NO ▼		
Is formula blenderized or aggressively mixed?	YES ▶	Let formula sit for 10-15 minutes before preparing pump delivery set for feeding. If foam is present in tubing, flush by priming pump delivery set either manually or with the pump and resume feeding.
▼ NO ▼		
Are air bubbles trapped inside the cassette?	YES ▶	Remove tubing from pump and manually prime tubing by turning bag upside down, gently squeezing lower half of bag while pinching the teal colored tubing just below the drop symbol. Hold this position until all air has passed through the teal segment of the tubing.
	NO ▶	If alarm continues, contact Moog Customer Service at 800.970.2337 for assistance.

LOAD SET Alarm

Is door closed securely?	NO/UNSURE ▶	Turn pump off. Unload and reload delivery set cassette. Make sure door is closed securely, then turn pump back on.
▼ YES ▼		
Is door cracked or tab on side of door broken?	YES ▶	If alarm continues, contact Moog Customer Service at 800.970.2337 to order a new door.
	NO ▶	If alarm continues, contact Moog Customer Service at 800.970.2337 for assistance.

ER01 - ER99 Alarms

Was pump door open while pump was turned on or while running?	YES/UNSURE ▶	Turn pump off. Unload and reload delivery set cassette. Make sure door is closed securely, then turn pump back on.
	NO ▶	If alarm continues, contact Moog Customer Service at 800.970.2337 for assistance.



Speak live with a Moog Clinical Representative for pump questions and troubleshooting guidance 24 hours per day, 7 days per week.

Clinical & Customer Support **800.970.2337**

Visit infinityfeedingpump.com for additional information

MOOG®

Enhancing Healthcare.
Enriching Lives.™

NO FLOW IN or NO FLOW OUT Alarm		
NO FLOW IN: Occlusion between delivery set and pump. NO FLOW OUT: Occlusion between pump and patient.		
Is delivery set tubing pinched or kinked?	YES ▶	Check delivery set for pinches or kinks in tubing and resume feeding.
▼ NO ▼		
Is tab on inside of door broken?	YES ▶	Contact Moog Customer Service at 800.970.2337 to order a new door.
▼ NO ▼		
Is pressure sensor region of cassette receptacle clean?	NO ▶	Clean pressure sensor area with a cotton swab, soft cloth, or dampened sponge; or wash entire pump under running water. Do not use abrasive materials or harsh chemicals.
▼ YES ▼*		
Are there visible signs of damage to pressure sensors area?	YES ▶	Contact Moog Customer Service at 800.970.2337 to return pump for service
	NO ▶	Disconnect feeding set from patient. Press the RUN key. If pump delivers food without alarm, check patient's feeding tube for obstruction. If alarm continues, remove set from pump, gently massage the "O" drop symbol, then <u>manually</u> prime set until occlusion is cleared and formula advances through tubing. Replace set and resume feeding. If unable to advance formula through tubing or alarm continues, contact Moog Customer Service at 800.970.2337 to return pump for assistance.
*Note: Do not use the PRIME key to troubleshoot or resolve these alarms.		

Charging Problems		
Is A/C adapter charger plugged into wall outlet and pump properly?	NO/UNSURE ▶	Check connections for both wall plug and pump adapter. Green indicator light on charger wall plug should be illuminated and pump display should have plug symbol with scrolling bars between E and F of fuel gauge. When pump is fully charged, bars will stop scrolling.
▼ YES ▼		
Is wall outlet functioning properly?	NO/UNSURE ▶	Plug another device into outlet to verify outlet is functioning properly.
▼ YES ▼		
Does charger adapter appear to have any damage?	YES ▶	Contact Moog Customer Service at 800.970.2337 to order a new charger
▼ NO ▼		
Does charger port appear to have any damage including bent or missing pins?	YES ▶	Contact Moog Customer Service at 800.970.2337 to return pump for service.
▼ NO ▼		
Is Battery Symbol and E and F of fuel gauge flashing?	YES ▶	Contact Moog Customer Service at 800.970.2337 to return pump for service.
	NO ▶	